



Parts Code / Parts Name

ER-1	:	Upper Case
ER-2	:	Lower Case
ER-3	:	Top Clover
ER-4	:	Magnet Guide Ring
ER-5	:	Dial Lever
ER-6	:	Spring Holder
ER-7	:	Flywheel + Alloy Rotor
ER-8	:	Magnet
ER-9	:	Spring
ER-10	:	Main Arm + Pressure Lever
ER-11	:	Sub Arm
ER-12	:	Pulley Holder
ER-13	:	Assistant Roller Holder
ER-14	:	Tension Lever
ER-26	:	Drive Roller (engraved)
ER-27	:	Assistant Roller (engraved)
F-1	:	Right Side Coupling
F-2	:	Left Side Coupling
F-4	:	Coupling Cover
F-7	:	Hub Clamp Handle
F-8	:	Wheel Position Adjust Knob
F-9	:	Plastic Cap (Grommet)
UF-13	:	Rubber Cap (45mm)
UF-18	:	RDA249 Frame
M8-4	:	Rubber Foot Cap (35mm)
SR-5	:	V-Belt (K-16)
SR-12	:	Cap Screw M6x18
SR-13	:	Reinforcement Plate
GM-22	:	Remote Shifter (White)